



Control at your fingertips

The Touch controls on this hob let you turn the heat up, down or off – immediately. They're precise and easy to use: just use a fingertip to gently slide to the temperature you need. You can be confident they'll do what you want them to at just the right moment, so you can create delicious meals faster.

Product Benefits & Features

Control at your fingertips

The Touch controls on this hob let you turn the heat up, down or off – immediately. They're precise and easy to use: just use a fingertip to gently slide to the temperature you need. You can be confident they'll do what you want them to at just the right moment, so you can create delicious meals faster.



- Direct Access: sliding touch control technology
- Controls position: Front Right
- Illuminated controls
- Left front zone: Hilight, Triple Circuit Round, 800/1600/2300W/120/175/210mm
- Left rear zone: Hilight, 1200W/145mm
- Middle front zone: No,
- Middle rear zone: No,
- Right front zone: Hilight, 1200W/145mm
- Right rear zone: Dual Circuit Oval, Hilight, 1500/2400W/170x265mm
- Automatic fast heating up
- Key-lock function
- Child safety lock function
- Hob safety: Automatic Switch Off
- Acoustic signal with switch off option
- CountUp Timer
- EcoTimer™
- Timer function
- CleverHeat™ function
- Easy installation thanks to snap-in system
- Main colour: Black


The perfect spot for your oval fish pan

Do justice to your ambitions with seafood. This hobs oval FishZone is perfect for creating a gentle, even heat under your fish pan.



Direct access to all your controls - thanks to the on-hob panel

This hob's controls are designed so that you can always access them straight away. Just reach over and make your adjustments.



Use your power with clever efficiency – thanks to the optimised power distribution

This induction hob has a clever power management system. It shares the power between your activated zones so that you can use your power with real efficiency.

Remembers where you left off

Whenever you get interrupted, you can put your cooking on hold with the Pause button. It makes sure nothing burns if you're called away from the kitchen and, conveniently, it remembers the different heats under all your pans. So when you're ready, one touch puts you back exactly where you left off.

Product Specification

BI dimensions HxWxD in mm	Not applicable
Dimensions WxD in mm	576x516
Colour	Black
Hob Energy type	Ceramic
Hob pan support	No
Optional accessories	No
Cord Length	1.5
Total electricity loading (W)	2800
Max power gas (W)	0
Voltage	220-240
Product Number Code	949 596 330
Color	Black
Country of origin	DE

