



# JUNIPER®

## FLUTES IONIAN ARRAY

### Remote Installation Guide



4IN HEIGHT - 24IN DIAMETER



4IN HEIGHT - 36IN DIAMETER

#### CARE INSTRUCTIONS

Gently wipe with a damp cloth to remove dirt, dust, and fingerprints.


Do not use any chemical cleaning solution.

Use indoors only.


**WARNING**

**A LICENSED ELECTRICIAN SHOULD PERFORM INSTALLATION IN ACCORDANCE WITH THE NATIONAL ELECTRIC CODE (NEC) AND RELEVANT LOCAL CODES. DISCONNECT MAIN POWER AT THE SOURCE PRIOR TO INSTALLATION. PREFERABLY TWO PEOPLE SHOULD BE INVOLVED IN THE INSTALLATION.**


**INSTRUCTIONS MEANT FOR A REMOTE CLASS 2 DRIVER.**

**1**

Attach the crossbar to the junction box using provided #8-32 screws. Install the provided 1/8 IPS nipple in the crossbar.

**2**


- A. Pass low voltage wires from junction box through the hole in the top cap assembly.
- B. Install the top cap assembly on the 1/8 IPS nipple using provided gripper as shown.

**3**

Press safety nut upwards and hold to pass aircraft cable through the gripper



Release safety nut to hold aircraft cable through in the gripper



- A. Loosen the safety nut on the aircraft cable gripper.
- B. Pass the aircraft cable from the fixture through hole in the canopy as shown.
- C. Partly loosen safety nut on cable gripper. Feed aircraft cable through the gripper.

4




FIGURE 4

Adjust aircraft cable length as needed. **Do not cut extra aircraft cable until desired suspension height is achieved.**

6




FIGURE 6

- A. Pass the power cord from the fixture through the bottom cap as shown. The #8-32 acts as a strain relief for the power cord.
- B. Connect wires according to diagram (wire nuts provided). **Wires to and from the driver are not included.**

5




FIGURE 5

- A. Connect the canopy to top cap assembly using provided M3 set screws.
- B. Loosen the M2.5 cap screw in bottom cap to release the bottom cap.

7




FIGURE 7

Push wires inside the canopy and insert the bottom cap into the canopy. Align the bottom cap with the canopy and tighten the M2.5 cap screw to fix the bottom cap in place.